

# Grip Step Applications

---

Year	VAN APPLICATIONS	Bracket Order No.	Step Board Order No.
	<b>CHEVROLET/GMC</b>		
03-13	Chevrolet Express/GMC Savana Short/Short (36" Step Boards)*	570340	415036
03-13	Chevrolet Express/GMC Savana Cut-A-Way Vans (Cab Only-36" Boards)*	570341	415036
03-13	Chevrolet Express/GMC Savana Long/Short (98" and 36" Step Boards)	570344	415100
2013	Chevrolet Express/GMC Savana - 135" Wheelbase Van	571345	415098
03-13	Chevrolet Express/GMC Savana - 135" Wheelbase Van* (Excludes Diesel)	570345	415098
2013	Chevrolet Express/GMC Savana - 155" Wheelbase Van*	571346	415114
03-12	Chevrolet Express/GMC Savana - 155" Wheelbase Van (Requires Bracket Package 570345 & 570346)	570345	415114
	* Driver Side Brkt may need to be notched on 2013+ GM Vans with A/C		
	<b>FORD</b>		
01-13	Ford E-Series Cut-A-Way Vans (36" Step Boards)	570121	415036
01-13	Ford E-Series Vans Long/Short (98" and 36" Step Boards)	570124	415100
01-13	Ford E-Series Vans Long/Long	570125	415098
	<b>SPRINTER</b>		
07-13	Sprinter Van Cab Only (36" Step Boards)	400741	415036
07-13	Sprinter Van Long/Short (98" and 36" Step Boards)	400744	415100
07-13	Sprinter Van Long/Long	400745	415098
07-13	Sprinter Van Rear Step (54" Length - Includes Brackets) (May Impact the Function of Backup Sensors if Equipped)	415740	
	<b>NISSAN</b>		
11-13	Nissan NV Cab Only (36" Step Boards)	401161	415036
11-13	Nissan NV Long/Short (98" and 36" Step Boards)	401164	415100